

# Connection to robair

**Olivier Aycard**

Grenoble INP - PHELMA

GIPSA Lab

<https://www.gipsa-lab.grenoble-inp.fr/user/olivier.aycard>

*olivier.aycard@grenoble-inp.fr*



# Outline

---

1. Connecting to the RobAIR: wireless connection;
2. ROS on robair: how it works;
3. Tests of connection to robair.

# Wireless hotspot connection

---

1. Turn on the robot with the blue push-button (takes ~ 2 mins to boot).
2. On your laptop, click on the wifi / network icon in the top-right corner of the screen.
3. Select the RobAIR\_hotspot\_ that matches the MAC address of your robot (written on top of the robot with a label).

**Example ssid:** RobAIR\_hotspot\_0cb6d2f1ff17

**Password:**      robairRobair42

4. Open a terminal (ctrl + alt + t) and check if you can ping the robot by typing the command:

```
ping 10.0.0.42
```

# Outline

---


1. Connecting to the RobAIR: wireless connection;
2. ROS on robair: how it works;
3. Tests of connection to robair.

# ROS on robair (1/5)


---

- Each robair publishes:
  - /scan (laserscanner data);
  - /odom (odometry).
- Each robair subscribes to:
  - /cmd\_vel to command robair in translation and/or rotation.


# ROS on robair (2/5)



# ROS on robair (3/5)




# ROS on robair (4/5)





# ROS on robair (5/5)



# Outline

---

1. Connecting to the RobAIR: wireless connection;
2. ROS on robair: how it works;
3. Tests of connection to robair.

# Tests of connection on robair

---

- We will check if you are able to receive the laser data (/scan topic) and send motion commands to robair (/cmd\_vel topic)
- In order to run a ros2 node, you must do the following:
  - Open a terminal (ctrl + alt + t), and run: `cd ~/ros2_ws`
  - Run: `source install/local_setup.bash`
  - Then, run the command for your node `ros2 run <package name> <node name>`

## 1. Laser data:

- Start rviz: `ros2 run rviz2 rviz2 -d src/follow_me/config/laser_only.rviz`
- You should see the data of the laser scanner

## 2. Motion commands:

- Start smooth\_teleop: `ros2 run smooth_teleop smooth_teleop_node`
- Use the keyboard to move robair. Press “k” to immediately stop.
- You should see robair moving