Connection to robair

Olivier Aycard

Professor

Grenoble INP - PHELMA

GIPSA Lab

https://www.gipsa-lab.grenoble-inp.fr/user/olivier.aycard

olivier.aycard@grenoble-inp.fr






Outline

- 1. Change the configuration to run our nodes on robair;
- 2. ROS on robair;
- 3. Tests of connection to robair.


1. You can run ROS nodes on your computer or on robair;




1. You can run ROS nodes on your computer or on robair;

```
student-3@robair: ~/Bureau
 FI.
Welcome to Ubuntu 20.04.3 LTS (GNU/Linux 5.11.0-37-generic x86_64)
Configuration: robair
                         Nodes are running on robair
student-3@robair:~/Bureau$
```

1. To change your configuration, run switch_config.sh in ~



1. To change your configuration, run switch_config.sh in ~




Outline

- 1. Change the configuration to run our nodes on robair;
- 2. ROS on robair;
- 3. Tests of connection to robair.


ROS on robair (1/5)

- You must be connected to robair with a wire to run nodes on robair
- Roscore is running on robair:
 - You do not have to run "roscore" on your laptop
- Each robair publishes:
 - /scan (laserscanner data);
 - /odom (odometry).
- Each robair subscribes to:
 - /cmd_vel to command robair in translation and/or rotation.


ROS on robair (2/5)




ROS on robair (3/5)



ROS on robair (4/5)



ROS on robair (5/5)



Outline

- 1. Change the configuration to run our nodes on robair;
- 2. ROS on robair;
- 3. Tests of connection to robair.

Tests of connection on robair

- You do not have to run "roscore" on your laptop
 - Roscore is now on robair
- We will check if you are able to receive the laser data (/scan topic) and send motion to robair (/cmd_vel topic)
- 1. Open a terminal and run rviz
 - You should see the data of the laser scanner
- 2. Open a terminal and run "rosrun teleoperation teleoperation_node.py"
 - Use the keyboard to move robair
 - You should see robair moving